



FIXTURE SHOWN WITH -MC MOUNTING CARRIER

INSTALLATION INSTRUCTIONS

A- ROUGH-IN FOR THE FOLLOWING.

- 5-1/2" RECESSED GASKET FLANGE (1).
- FLUSH VALVE INLET 1" NPT (2).
- FIXTURE FLUSHING INLET 1-1/2" NPT (14).

B- FOR UNITS WITHOUT MOUNTING CARRIER.

ATTACH MOUNTING CHANNEL (7) (FIXTURE SIDE) TO REINFORCED WALL. POSITION MOUNTING CHANNEL (7) TO MATCH MOUNTING LOCATIONS SHOWN. WALL ANCHORS & FASTENERS ARE BY OTHERS.

C- FOR UNITS WITH MOUNTING CARRIER.

INSTALL MOUNTING CARRIER (PLUMBING SIDE OF WALL) (3) TO FLOOR. ATTACH 1/2" UNC STUDS (4) TO CARRIER (3) USING NUTS (6) & WASHERS (5).

ATTACH MOUNTING CHANNEL (7) (FIXTURE SIDE OF WALL) TO EXISTING 1/2" STUDS WITH NUTS (8) AND WASHERS (13). SEE DETAIL A-A.

D- PLACE TOILET (9) UP AGAINST WALL. ATTACH TOILET HOUSING (9) TO MOUNTING CHANNEL (7) BY USING 1/4"-20 SCREWS (10) SEE DETAIL B-B.

E- REMOVE ACCESS PANEL (11) MAKE UP TOILET WASTE CONNECTION.

F- FOR OPTIONAL -FV FLUSH VALVE:

CONNECT FLUSH VALVE (12) AS REQUIRED FOR EXPOSED INSTALLATION PER MANUFACTURERS' RECOMMENDATIONS.

NOTES:

FOR SUFFIX OPTION -ADA UNITS, REFER TO ADA ACCESSIBILITY GUIDELINES FOR COMPLETE INSTALLATION REQUIREMENTS.

1- ALL VERTICAL DIMENSIONS CHANGE ACCORDING TO ADDITIONAL SEAT HEIGHT FOR -ADA I.E. FOR 18" SEAT HEIGHT, FLUSH VALVE INLET BECOMES 29-1/2".

2- FLUSH VALVE MUST BE HYDRAULICALLY ACTUATED OR SUPPLIED WITH AN -ADA HANDLE, MAX. CONTROL HEIGHT IS 44" ABOVE FINISHED FLOOR. CONTROLS MUST BE LOCATED ON WIDE SIDE OF TOILET.

TOP SUPPLY, OFF-FLOOR, WALL OUTLET TOILET 8955-T-1

NEO-METRO
P.O. BOX 3527 • CITY OF INDUSTRY, CA 91744 USA
800-591-9050 • 626-855-4854 • www.neo-metro.com

TITLE TOP SUPPLY, SIPHON, OFF-FLOOR, WALL OUTLET TOILET - MODEL # 8955-T-1

MANUFACTURE DATE
SEPTEMBER 2001
TO PRESENT

DATE ISSUED
09/05/01
DATE REVISED

DRAWING NUMBER
9935-032-001