



### INSTALLATION INSTRUCTIONS:

- A- Rough-in for bidet 1-1/2" O.D. waste outlet with centerline (1) of fixture recommended minimum of 18" from finished wall.
- B- Rough-in for valve by others.
- C- Remove access plates (2) from bidet housing both sides.

- D- Position bidet against wall in location to be mounted. Install mounting hardware (3) by others.
- E- Make up waste connection (4).
- F- Install valve by others according to valve manufacturers' instructions.
- G- Replace access plates (2) with screws (5) provided.

<b>NEO-METRO</b> P.O. BOX 3527 • CITY OF INDUSTRY, CA 91744 USA 800-591-9050 • 626-855-4854 • www.neo-metro.com	<b>TITLE</b> <b>NEO-METRO COLLECTION BIDET MODEL # 8964</b>	
	<b>MANUFACTURE DATE</b> <b>OCTOBER 2001</b> <b>TO PRESENT</b>	<b>DATE ISSUED</b> <b>05/21/02</b> <b>DATE REVISED</b>