



FIXTURE SHOWN WITH -MC MOUNTING CARRIER

### INSTALLATION INSTRUCTIONS

A- ROUGH-IN FOR THE FOLLOWING.

- 7-1/2" RECESSED GASKET FLANGE ①.
- FLUSH VALVE INLET 1" NPT ②.
- FIXTURE FLUSHING INLET 1-1/2" NPT ⑮.

B- FOR OPTIONAL 2898 FLUSH VALVE ACCESS PANEL ③:  
FOR BACK SUPPLY FLUSH VALVES. SEE DRAWING #9908-399-001.

C- FOR UNITS WITHOUT MOUNTING CARRIER.  
ATTACH MOUNTING CHANNEL ⑧ (FIXTURE SIDE) OF REINFORCED WALL. POSITION MOUNTING CHANNEL ⑧ TO MATCH MOUNTING LOCATIONS SHOWN. WALL ANCHORS & FASTENERS ARE BY OTHERS.

D- FOR UNITS WITH MOUNTING CARRIER.  
INSTALL MOUNTING CARRIER (PLUMBING SIDE OF WALL) ④ TO FLOOR. ATTACH 1/2" UNC STUDS ⑤ TO CARRIER ④ USING NUTS ⑦ & WASHERS ⑥. ATTACH MOUNTING CHANNEL ⑧ (FIXTURE SIDE) OF WALL TO EXISTING 1/2" STUDS WITH NUTS ⑨ AND WASHERS ⑭. SEE DETAIL A-A.

E- PLACE TOILET ⑩ UP AGAINST WALL. ATTACH TOILET HOUSING ⑩ TO MOUNTING CHANNEL ⑧ BY USING 1/4"-20 SCREWS ⑪. SEE DETAIL B-B.  
F- REMOVE ACCESS PANEL ⑫. MAKE UP TOILET WASTE CONNECTION.

G- FOR OPTIONAL -FV FLUSH VALVE:  
CONNECT FLUSH VALVE ⑬ AS REQUIRED FOR CONCEALED INSTALLATION PER MANUFACTURERS' RECOMMENDATIONS.

**NOTES:**  
FOR SUFFIX OPTION -ADA UNITS, REFER TO ADA ACCESSIBILITY GUIDELINES FOR COMPLETE INSTALLATION REQUIREMENTS.

- 1- ALL VERTICAL DIMENSIONS CHANGE ACCORDING TO ADDITIONAL SEAT HEIGHT FOR -ADA I.E. FOR 18" SEAT HEIGHT, -W FLUSHING INLET BECOMES 18-1/4".
- 2- FLUSH VALVE MUST BE HYDRAULICALLY ACTUATED OR SUPPLIED WITH AN -ADA HANDLE, MAX. CONTROL HEIGHT IS 44" ABOVE FINISHED FLOOR. CONTROLS MUST BE LOCATED ON WIDE SIDE OF TOILET.

## WALL SUPPLY, ON-FLOOR, FLOOR OUTLET TOILET 8955-W-3

NEO-METRO

P.O. BOX 3527 • CITY OF INDUSTRY, CA 91744 USA  
800-591-9050 • 626-855-4854 • www.neo-metro.com

TITLE

**WALL SUPPLY, SIPHON, ON-FLOOR, FLOOR OUTLET TOILET - MODEL • 8955-W-3**

MANUFACTURE DATE

**SEPTEMBER 1999**

**TO PRESENT**

DATE ISSUED

**09/08/99**

DATE REVISED

**09/05/01**

DRAWING NUMBER

**9935-035-001**